

Printer Compatibilities List for TL-PS110U/TL-PS110P/TL-WPS510U

Update:2012-11-01

Note: "OK" means the print server is compatible with the printer;

" \ " means the print server is not compatible with the printer;

"—" means the function is not tested;

PCL and PS are supported by our print servers. If the printer is not on the list, please check the printing language by yourself. If it is PCL or PS, it should be compatible with our print server. If not, it is more probably incompatible.

The product only supports the printing function of the Multi Function Printer.

No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
1	HP	Business InkJet 1000	OK		OK
2	HP	Color LaserJet 1500L	OK		—
3	HP	Color LaserJet 1600	OK		OK
4	HP	Color LaserJet 2500	OK	OK	OK
5	HP	Color LaserJet 2550	OK	OK	OK
6	HP	Color LaserJet 2550L/LN	OK		OK
7	HP	Color LaserJet 2600	OK		OK
8	HP	Color LaserJet 2605	OK	OK	OK
9	HP	Color LaserJet 2700n	OK		OK
10	HP	Color LaserJet 2840	OK		OK
11	HP	Color LaserJet 3700	OK	OK	OK
12	HP	Color LaserJet 4000		OK	
13	HP	Color LaserJet 4100		OK	
14	HP	Color LaserJet 4500		OK	
15	HP	Color LaserJet 4650	OK	OK	OK
16	HP	Color LaserJet 4650 Color LaserJet		OK	
17	HP	Color LaserJet CP1215	OK		OK
18	HP	Color LaserJet CP1525nw	OK		OK
19	HP	Color LaserJet CM1312 MFP	OK		OK
20	HP	Color LaserJet CM1015 MFP	OK		OK
21	HP	DesignJet 100	OK	OK	OK
22	HP	DesignJet 450	—	OK	—
23	HP	DesignJet 600		OK	
24	HP	DesignJet 650C		OK	
25	HP	DesignJet 700		OK	
26	HP	DesignJet 750C+		OK	
27	HP	DeskJet 1120C		OK	
28	HP	Deskjet 1125C	OK	OK	OK
29	HP	Deskjet 1180C	OK	OK	OK
30	HP	DeskJet 1280	OK	OK	OK
31	HP	Deskjet 2000 J210	OK		OK
32	HP	Deskjet 2050	OK		OK
33	HP	Deskjet 3000	OK		OK
34	HP	Deskjet 3050	OK		OK
35	HP	Deskjet 3325	OK		OK
36	HP	DeskJet 3420	OK		OK
37	HP	Deskjet 3520	OK		OK
38	HP	Deskjet 3535	OK		OK
39	HP	Deskjet 3650	OK		OK
40	HP	Deskjet 3743	OK		OK
41	HP	Deskjet 3748	OK		OK
42	HP	Deskjet 3820	OK	OK	OK
43	HP	DeskJet 3920	OK		OK
44	HP	DeskJet 3940	OK		OK
45	HP	DeskJet 400/420		OK	
46	HP	Deskjet 450C	OK	OK	OK
47	HP	Deskjet 5150	OK	—	—
48	HP	DeskJet 5440	OK		OK
49	HP	DeskJet 5500		OK	
50	HP	Deskjet 5550	OK	OK	OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
51	HP	Deskjet 5652	OK	OK	OK
52	HP	Deskjet 670C		OK	

53	HP	Deskjet 680C		OK	
54	HP	Deskjet 720C		OK	
55	HP	Deskjet 810C	OK	OK	OK
56	HP	Deskjet 830C	OK	OK	OK
57	HP	Deskjet 845C	OK		OK
58	HP	DeskJet 9300	OK	OK	OK
59	HP	Deskjet 948c	OK	OK	OK
60	HP	Deskjet 9600	OK	OK	OK
61	HP	Deskjet 9650	OK	OK	OK
62	HP	Deskjet 970c XI	OK	OK	OK
63	HP	Deskjet 9800	OK	OK	OK
64	HP	Deskjet D1560	OK		OK
65	HP	Deskjet D2560	OK		OK
66	HP	Deskjet D5560	OK		OK
67	HP	DeskJet F370	OK		OK
68	HP	DeskJet F380	OK		OK
69	HP	DeskJet F4185	OK		OK
70	HP	DeskJet F4280	OK		OK
71	HP	Deskjet F4480	OK		OK
72	HP	LaserJet Pro CP1525N	—	—	OK
73	HP	LaserJet 1100		OK	
74	HP	LaserJet 1010	OK	—	—
75	HP	LaserJet 1160	OK	OK	OK
76	HP	LaserJet 1200	OK	OK	OK
77	HP	LaserJet 1220	OK	OK	OK
78	HP	LaserJet 1300	OK	OK	OK
79	HP	LaserJet 1320	OK	OK	OK
80	HP	LaserJet M1522n MFP	OK		OK
81	HP	LaserJet 2055d	OK	—	—
82	HP	LaserJet 2100		OK	
83	HP	LaserJet 2200d	OK	OK	OK
84	HP	LaserJet 2300	OK	OK	OK
85	HP	LaserJet 2410	OK	OK	OK
86	HP	LaserJet 2420	OK	OK	OK
87	HP	LaserJet 2550	OK	OK	OK
88	HP	LaserJet 3015	OK	OK	OK
89	HP	LaserJet 3050	OK		OK
90	HP	LaserJet 3055	OK		OK
91	HP	LaserJet 3200	OK	OK	OK
92	HP	LaserJet 3330	OK	OK	OK
93	HP	LaserJet 3330mfp	OK	OK	OK
94	HP	LaserJet 3380	OK		OK
95	HP	LaserJet 4000		OK	
96	HP	LaserJet 4050		OK	
97	HP	LaserJet 4100 /4100n		OK	
98	HP	LaserJet 4250	OK	OK	OK
99	HP	LaserJet 4300n		OK	
100	HP	LaserJet 4300tn/dtn		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
101	HP	LaserJet 4500		OK	
102	HP	LaserJet 4650	OK	OK	OK
103	HP	LaserJet 5100fn/tn		OK	
104	HP	LaserJet 5100le/se		OK	
105	HP	LaserJet 6P / 6L		OK	
106	HP	LaserJet 8100		OK	
107	HP	LaserJet M1120 MFP	OK		OK
108	HP	LaserJet M1319F MFP	OK		OK
109	HP	LaserJet P1102	OK	—	OK
110	HP	LaserJet P2015	OK		OK
111	HP	LaserJet P2035n	OK		—
112	HP	LaserJet Professional P1566	OK		—
113	HP	OfficeJet J3608	OK		OK
114	HP	OfficeJet 4255	OK		OK
115	HP	OfficeJet 4255	OK		OK

116	HP	OfficeJet 4500	OK		OK
117	HP	OfficeJet 4610	OK		OK
118	HP	OfficeJet 4620	OK		OK
119	HP	OfficeJet 5610	OK		OK
120	HP	OfficeJet J5780	OK		OK
121	HP	OfficeJet 6210	OK		OK
122	HP	OfficeJet 6310	OK		OK
123	HP	OfficeJet 6000	OK		OK
124	HP	OfficeJet 6100 ePrint	OK		OK
125	HP	OfficeJet 6500	OK		OK
126	HP	OfficeJet 6600	OK		OK
127	HP	OfficeJet 7000	—		OK
128	HP	OfficeJet 7500A	OK		OK
129	HP	OfficeJet 7210	OK		OK
130	HP	OfficeJet J4580	OK		OK
131	HP	OfficeJet J4660	OK		OK
132	HP	OfficeJet J6480	OK		OK
133	HP	OfficeJet K7100	OK		OK
134	HP	OfficeJet K850	OK	OK	OK
135	HP	OfficeJet Pro K5300	OK		OK
136	HP	OfficeJet Pro K550	OK		OK
137	HP	OfficeJet Pro 8100	OK		OK
138	HP	OfficeJet Pro K8600	OK		OK
139	HP	OfficeJet Pro 8600	OK		OK
140	HP	OfficeJet Pro 8600 Plus	OK		OK
141	HP	OfficeJet Pro L7380	OK		OK
142	HP	OfficeJet Pro L7590	OK		OK
143	HP	OfficeJet Pro 6500A Plus	OK		OK
144	HP	OfficeJet Pro 7000	OK		OK
145	HP	OfficeJet Pro 8000	OK		OK
146	HP	OfficeJet Pro 8500A Plus	OK		OK
147	HP	OfficeJet Pro 8500W	OK		OK
148	HP	Photosmart 2610	OK		OK
149	HP	Photosmart 3110	OK		OK
150	HP	Photosmart 5510	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
151	HP	Photosmart 5520	OK		OK
152	HP	Photosmart 6510	OK		OK
153	HP	Photosmart 7150	OK		OK
154	HP	Photosmart 7200	OK		OK
155	HP	Photosmart 7510	OK		OK
156	HP	Photosmart 7550	OK		OK
157	HP	Photosmart 7660	OK		OK
158	HP	Photosmart 7830	OK		OK
159	HP	Photosmart 7900	OK		OK
160	HP	Photosmart 8200	OK		OK
161	HP	Photosmart Plus B209a	OK		OK
162	HP	Photosmart Plus B210a	OK		OK
163	HP	Photosmart Plus C310a	OK		OK
164	HP	Photosmart A520	OK		OK
165	HP	Photosmart B109a	OK		OK
166	HP	Photosmart B110a AIO	OK		OK
167	HP	Photosmart C309a	OK		OK
168	HP	Photosmart C410a	OK		OK
169	HP	Photosmart C3180	OK		OK
170	HP	Photosmart C4180	OK		OK
171	HP	Photosmart C4200	OK	—	—
172	HP	Photosmart C4280	OK		OK
173	HP	Photosmart C4385	OK		OK
174	HP	Photosmart C4480	OK		OK
175	HP	Photosmart C4580	OK		OK
176	HP	Photosmart C5180	OK		OK
177	HP	Photosmart C5280	OK		OK

178	HP	Photosmart C5380	OK		OK
179	HP	Photosmart C6180	OK		OK
180	HP	Photosmart C6280	OK		OK
181	HP	Photosmart C6380	OK		OK
182	HP	Photosmart C7180	OK		OK
183	HP	Photosmart C7280	OK		OK
184	HP	Photosmart C8180	OK		OK
185	HP	Photosmart D5160	OK		OK
186	HP	Photosmart D5360	OK		OK
187	HP	Photosmart D5460	OK		OK
188	HP	Photosmart D7160	OK		OK
189	HP	Photosmart D7260	OK		OK
190	HP	Photosmart D7360	OK		OK
191	HP	Photosmart Premium C309g	OK		OK
192	HP	Photosmart Premium C310g	OK		OK
193	HP	PSC 1210			OK
194	HP	PSC 1315	OK		OK
195	HP	PSC 1350	OK		OK
196	HP	PSC 1410	OK		OK
197	HP	PSC 1610	OK		OK
198	HP	PSC 2210	OK		OK
199	HP	PSC 2310	OK		OK
200	EPSON	Aculaser C1100SE	OK	OK	OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
201	EPSON	Aculaser C1100N	OK	—	—
202	EPSON	Aculaser C1700	OK		OK
203	EPSON	Aculaser C1750N	OK		OK
204	EPSON	Aculaser C1750W	OK		OK
205	EPSON	Aculaser C1900	OK	OK	OK
206	EPSON	Aculaser C2900	OK		OK
207	EPSON	Aculaser C3800	OK		OK
208	EPSON	Aculaser C3900N	OK		OK
209	EPSON	Aculaser C9100	OK		OK
210	EPSON	Aculaser CX16NF	OK		OK
211	EPSON	Aculaser CX17NF	OK		OK
212	EPSON	Aculaser M1400	OK		OK
213	EPSON	Aculaser M2010DN	OK		OK
214	EPSON	Aculaser M2010D	OK	OK	OK
215	EPSON	Aculaser M2310D	OK	OK	OK
216	EPSON	Aculaser M2310DN	OK		OK
217	EPSON	Aculaser M2410D	OK	OK	OK
218	EPSON	Aculaser M2410DN	OK		OK
219	EPSON	Aculaser MX14	OK		OK
220	EPSON	Aculaser MX14NF	OK		OK
221	EPSON	AL-M7000	OK		OK
222	EPSON	B-508DN	OK		OK
223	EPSON	C750	OK	OK	OK
224	EPSON	CC-500L	OK		OK
225	EPSON	CL-760	OK		OK
226	EPSON	E-300L	OK		OK
227	EPSON	E-520	OK		OK
228	EPSON	E-720	OK		OK
229	EPSON	EC-01	OK		OK
230	EPSON	EPL 5700		OK	
231	EPSON	EPL 5700		OK	
232	EPSON	EPL 5800	OK	OK	OK
233	EPSON	EPL 5800	OK	OK	OK
234	EPSON	EPL 5900	OK	OK	OK
235	EPSON	EPL 5900	OK	OK	OK
236	EPSON	EPL 6100	OK	OK	OK
237	EPSON	EPL 6200	OK	OK	OK
238	EPSON	Aculaser C1600	OK		OK
239	EPSON	B-518DN	OK		OK
240	EPSON	EPL 6200	OK	OK	OK

241	EPSON	EPL N2120		OK	
242	EPSON	K100	OK		OK
243	EPSON	L200	OK		OK
244	EPSON	L300	OK		OK
245	EPSON	L800	OK		OK
246	EPSON	LP2500	OK		OK
247	EPSON	LP-7700	OK		OK
248	EPSON	LP-8700	OK		OK
249	EPSON	LP-8800C	OK		OK
250	EPSON	LP8900	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
251	EPSON	LP-9500C	OK		OK
252	EPSON	LQ 100		OK	
253	EPSON	LQ 1000C		OK	
254	EPSON	LQ 1170+		OK	
255	EPSON	LQ 1170C		OK	
256	EPSON	LQ 1170C+		OK	
257	EPSON	LQ 2070C		OK	
258	EPSON	LQ 2080C		OK	
259	EPSON	LQ 2090		OK	
260	EPSON	LQ 2090C	OK	OK	OK
261	EPSON	LQ 2170C		OK	
262	EPSON	LQ 2180C		OK	
263	EPSON	LQ 2190C	OK	OK	OK
264	EPSON	LQ 2550		OK	
265	EPSON	LQ 300		OK	
266	EPSON	LQ 300+		OK	
267	EPSON	LQ 300+II	OK	OK	OK
268	EPSON	LQ 3500C		OK	
269	EPSON	LQ 570C		OK	
270	EPSON	LQ 670		OK	
271	EPSON	LQ 680		OK	
272	EPSON	LQ 680C		OK	
273	EPSON	ME 320	OK		OK
274	EPSON	ME 340	OK		OK
275	EPSON	ME Office 82WD	OK		OK
276	EPSON	ME Office 900WD	OK		OK
277	EPSON	ME Office 940FW	OK		OK
278	EPSON	ME Office 960FWD	OK		OK
279	EPSON	MC-2000	OK		OK
280	EPSON	PictureMate PM250	OK		OK
281	EPSON	PLQ-20C	OK		OK
282	EPSON	PLQ-20CM	OK		OK
283	EPSON	PM-860PT	OK		OK
284	EPSON	PM-890C	OK		OK
285	EPSON	PM-920C	OK		OK
286	EPSON	PM-930C	OK		OK
287	EPSON	PM-950C	OK		OK
288	EPSON	PM-970C	OK		OK
289	EPSON	PM-980C	OK		OK
290	EPSON	PM-A550	OK		OK
291	EPSON	PM-A620	OK		OK
292	EPSON	PM-A650	OK		OK
293	EPSON	PM-A720	OK		OK
294	EPSON	PM-A820	OK		OK
295	EPSON	PM-A840	OK		OK
296	EPSON	PM-A850	OK		OK
297	EPSON	PM-A890	OK		OK
298	EPSON	PM-A900	OK		OK
299	EPSON	PM-A920	OK		OK
300	EPSON	PM-A940	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
301	EPSON	PM-A950	OK		OK
302	EPSON	PM-A970	OK		OK
303	EPSON	PM-2200C	OK		OK

304	EPSON	PM-3500C	OK		OK
305	EPSON	PM-3700C	OK		OK
306	EPSON	PM-4000PX	OK		OK
307	EPSON	PM-D800	OK		OK
308	EPSON	PM-D870	OK		OK
309	EPSON	PM-D1000	OK		OK
310	EPSON	PM-FA700	OK		OK
311	EPSON	PM-G800	OK		OK
312	EPSON	PM-G820	OK		OK
313	EPSON	PM-G850	OK		OK
314	EPSON	PM-G860	OK		OK
315	EPSON	PM-G4500	OK		OK
316	EPSON	PM-T960	OK		OK
317	EPSON	PM-T990	OK		OK
318	EPSON	PX-5000	OK		OK
319	EPSON	PX-A640	OK		OK
320	EPSON	PX-A740	OK		OK
321	EPSON	PX-G5300	OK		OK
322	EPSON	PX-G5100	OK		OK
323	EPSON	PX-G930	OK		OK
324	EPSON	PX-G5000	OK		OK
325	EPSON	PX-V780	OK		OK
326	EPSON	RX 510	OK		OK
327	EPSON	RX 530	OK		OK
328	EPSON	RX 590	OK		OK
329	EPSON	RX 630	OK		OK
330	EPSON	RX 690	OK		OK
331	EPSON	Stylus C20	OK		OK
332	EPSON	Stylus C40	OK		OK
333	EPSON	Stylus C41UX/SX	OK		OK
334	EPSON	Stylus C43UX	OK		OK
335	EPSON	Stylus C45	OK		OK
336	EPSON	Stylus C59	OK		OK
337	EPSON	Stylus C60	OK	OK	OK
338	EPSON	Stylus C63	OK	OK	OK
339	EPSON	Stylus C67	OK	OK	OK
340	EPSON	Stylus C79	OK		OK
341	EPSON	Stylus C83		OK	
342	EPSON	Stylus C90	OK		OK
343	EPSON	Stylus Color 1160	OK		OK
344	EPSON	Stylus Color 1500	OK		OK
345	EPSON	Stylus Color 1520	OK		OK
346	EPSON	Stylus Color 400		OK	
347	EPSON	Stylus Color 600		OK	
348	EPSON	Stylus Color 670	OK	OK	OK
349	EPSON	Stylus Color 800	OK	OK	OK
350	EPSON	Stylus Color 810	OK	OK	OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
351	EPSON	Stylus Color 850	OK	OK	OK
352	EPSON	Stylus Color 900	OK		OK
353	EPSON	Stylus CX-1500	OK		OK
354	EPSON	Stylus CX-2900	OK		OK
355	EPSON	Stylus CX-3500	OK		OK
356	EPSON	Stylus CX-3700	OK		OK
357	EPSON	Stylus CX-3900	OK		OK
358	EPSON	Stylus CX-4100	OK		OK
359	EPSON	Stylus CX-4700	OK		OK
360	EPSON	Stylus CX-4900	OK		OK
361	EPSON	Stylus CX-5300	OK		OK
362	EPSON	Stylus CX-5500	OK		OK
363	EPSON	Stylus CX-5505	OK		OK
364	EPSON	Stylus CX-5900	OK		OK
365	EPSON	Stylus CX-6900F	OK		OK
366	EPSON	Stylus CX-7300	OK		OK
367	EPSON	Stylus CX-7800	OK		OK

368	EPSON	Stylus CX-8300	OK		OK
369	EPSON	Stylus CX-9300F	OK		OK
370	EPSON	Stylus Office T30	OK		OK
371	EPSON	Stylus Office T40W	OK		OK
372	EPSON	Stylus Office TX300F	OK		OK
373	EPSON	Stylus Office TX320F	OK		OK
374	EPSON	Stylus Office TX510FN	OK		OK
375	EPSON	Stylus Office TX600FW	OK		OK
376	EPSON	Stylus Office TX610FW	OK		OK
377	EPSON	Stylus Office T1100	OK		OK
378	EPSON	Stylus Photo 915	OK		OK
379	EPSON	Stylus Photo 1270	OK	OK	OK
380	EPSON	Stylus Photo 1290	OK		OK
381	EPSON	Stylus Photo 1390	OK		OK
382	EPSON	Stylus Photo 2100	OK		OK
383	EPSON	Stylus Photo 710	OK		OK
384	EPSON	Stylus Photo 720	OK		OK
385	EPSON	Stylus Photo 790	OK		OK
386	EPSON	Stylus Photo 810	OK	OK	OK
387	EPSON	Stylus Photo 830U	OK		OK
388	EPSON	Stylus Photo 900	OK	OK	OK
389	EPSON	Stylus Photo 915	OK		OK
390	EPSON	Stylus Photo EX2	OK	OK	OK
391	EPSON	Stylus Photo EX3	OK	OK	OK
392	EPSON	Stylus Photo R1800	OK	OK	OK
393	EPSON	Stylus Photo R210	OK		OK
394	EPSON	Stylus Photo R230	OK		OK
395	EPSON	Stylus Photo R250	OK		OK
396	EPSON	Stylus Photo R270	OK		OK
397	EPSON	Stylus Photo R310	OK		OK
398	EPSON	Stylus Photo R350	OK		OK
399	EPSON	Stylus Photo R2400	OK		OK
400	EPSON	Stylus Photo R800	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
401	EPSON	Stylus Photo RX430	OK		OK
402	EPSON	Stylus Photo RX 510	OK		OK
403	EPSON	Stylus Photo RX 530	OK		OK
404	EPSON	Stylus Photo RX 590	OK		OK
405	EPSON	Stylus Photo RX 630	OK		OK
406	EPSON	Stylus Photo RX 650	OK		OK
407	EPSON	Stylus Photo RX 690	OK		OK
408	EPSON	Stylus Photo R2880	OK		OK
409	EPSON	Stylus Photo TX700W	OK		OK
410	EPSON	Stylus Photo TX800FW	OK		OK
411	EPSON	Stylus Photo TX820FWD	OK		OK
412	EPSON	Stylus Pro 7600	OK	OK	OK
413	EPSON	Stylus TX550W	OK		OK
414	EPSON	Stylus TX420W	OK		OK
415	EPSON	Stylus TX410	OK		OK
416	EPSON	Stylus TX430	OK		OK
417	EPSON	Stylus TX235	OK		OK
418	EPSON	Stylus TX220	OK		OK
419	EPSON	Stylus TX200	OK		OK
420	EPSON	Stylus TX210	OK		OK
421	EPSON	Stylus TX130	OK		OK
422	EPSON	Stylus TX110	OK		OK
423	EPSON	Stylus TX100	OK		OK
424	EPSON	Stylus T22	OK		OK
425	EPSON	Stylus T20	OK		OK
426	EPSON	Stylus T21	OK		OK
427	EPSON	Stylus Photo T50	OK		OK
428	EPSON	TM883 (III)		OK	
429	EPSON	TM T88III		OK	
430	EPSON	WF-7011	OK		OK
431	EPSON	WP-4531	OK		OK

432	EPSON	WP-4091	OK		OK
433	EPSON	XP30	OK		OK
434	EPSON	XP-102	OK		OK
435	EPSON	XP-202	OK		OK
436	EPSON	XP-302	OK		OK
437	EPSON	XP-402	OK		OK
438	Canon	BJ-330		OK	
439	Canon	BJC-4200		OK	
440	Canon	BJC-4300		OK	
441	Canon	BJC-4500			
442	Canon	BJC-4550		OK	
443	Canon	BJC-4600		OK	
444	Canon	BJF9000	OK		OK
445	Canon	D380	OK		OK
446	Canon	I-255	OK		OK
447	Canon	I-355	OK		OK
448	Canon	I-450	OK		OK
449	Canon	I-455	OK		OK
450	Canon	I-470D	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
451	Canon	I-475D	OK		OK
452	Canon	I-550	OK		OK
453	Canon	I-560	OK		OK
454	Canon	I-850	OK		OK
455	Canon	I-865	OK		OK
456	Canon	I-950	OK		OK
457	Canon	I-6100	OK	OK	OK
458	Canon	I-6500	OK	OK	OK
459	Canon	I-9100	OK		OK
460	Canon	I-9950	OK		OK
461	Canon	IR 1025IF	OK	—	—
462	Canon	IX4000	OK		OK
463	Canon	IX5000	OK		OK
464	Canon	Imageclass D380	OK		OK
465	Canon	MP-160	OK		OK
466	Canon	MP-638	OK		OK
467	Canon	MP 770	OK		OK
468	Canon	MP 800	OK	—	—
469	Canon	MX318	OK		OK
470	Canon	MX320	OK		OK
471	Canon	MX700	OK		OK
472	Canon	NP630	—	—	OK
473	Canon	PIXUS IP2500	OK		OK
474	Canon	PIXUS 990i	OK		OK
475	Canon	PIXMA iP1000	OK		OK
476	Canon	PIXMA iP1700	OK		OK
477	Canon	PIXMA iP1800	OK		OK
478	Canon	PIXMA Ip1880	OK		OK
479	Canon	PIXMA Ip1980	OK		OK
480	Canon	PIXMA Ip2000	OK		OK
481	Canon	PIXMA iP3000	OK		OK
482	Canon	PIXMA Ip3300	OK		OK
483	Canon	PIXMA Ip3500	OK		OK
484	Canon	PIXMA Ip3680	OK		OK
485	Canon	PIXMA iP4000	OK	OK	OK
486	Canon	PIXMA Ip4200	OK		OK
487	Canon	PIXMA Ip4300	OK		OK
488	Canon	PIXMA Ip4500	OK		OK
489	Canon	PIXMA Ip4600	—	—	OK
490	Canon	PIXMA Ip4760	OK		OK
491	Canon	PIXMA ip4970	OK		OK
492	Canon	PIXMA Ip5000	OK		OK
493	Canon	PIXMA Ip6000	OK		OK
494	Canon	PIXMA Ip8500	OK		OK
495	Canon	PIXMA MG6170	OK		OK

496	Canon	PIXMA MG6270	OK		OK
497	Canon	PIXMA MP110	OK		OK
498	Canon	PIXMA MP130	OK		OK
499	Canon	PIXMA MP145	OK		OK
500	Canon	PIXMA MP150	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
501	Canon	PIXMA MP180	OK		OK
502	Canon	PIXMA MP258	OK		OK
503	Canon	PIXMA MP450	OK		OK
504	Canon	PIXMA MP730	OK		OK
505	Canon	PIXMA MP780	OK		OK
506	Canon	PIXMA MP830	OK		OK
507	Canon	PIXMA MX357	OK		OK
508	Canon	PIXMA MX416	OK		OK
509	Canon	S-200SPX	OK		OK
510	Canon	S-520		OK	
511	Lexmark	C720		OK	
512	Lexmark	E230	OK		OK
513	Lexmark	E322	OK	OK	OK
514	Lexmark	Optra S1250		OK	
515	Lexmark	P4350	OK		OK
516	Lexmark	P6250	OK		OK
517	Lexmark	T420	OK	OK	OK
518	Lexmark	T620	OK	OK	OK
519	Lexmark	W812	OK	OK	OK
520	Lexmark	Z42	OK		OK
521	Lexmark	Z43	OK	OK	OK
522	Lexmark	Z45	OK		OK
523	Lexmark	Z55	OK	OK	OK
524	Lexmark	Z515	OK	OK	OK
525	Lexmark	Z615	OK		OK
526	Lexmark	Z705	OK	OK	OK
527	FUJI Xerox	Able 3321		OK	
528	FUJI Xerox	DL700		OK	
529	FUJI Xerox	DL900		OK	
530	FUJI Xerox	DL-3400		OK	
531	FUJI Xerox	DL-3800		OK	
532	FUJI Xerox	DL-3850		OK	
533	FUJI Xerox	DL-5800		OK	
534	FUJI Xerox	DL-6400Pro		OK	
535	FUJI Xerox	DL-6800		OK	
536	FUJI Xerox	DocuPrint 2050	OK	OK	OK
537	FUJI Xerox	DocuPrint 240A	OK	OK	OK
538	FUJI Xerox	DocuPrint C1110B	OK		OK
539	FUJI Xerox	DocuPrint CM205 f	OK		OK
540	FUJI Xerox	DocuPrint CP105 b	OK		OK
541	FUJI Xerox	DocuPrint P205 b	OK		OK
542	FUJI Xerox	DocuPrint M205 b	OK		OK
543	FUJI Xerox	DocuPrint M205 f	OK		OK
544	FUJI Xerox	DocuPrint M205 fw	OK		OK
545	FUJI Xerox	FP 410	—	OK	
546	FUJI Xerox	Jet Wind 500C		OK	
547	FUJI Xerox	Phaser 3310	OK	OK	OK
548	FUJI Xerox	PP 10		OK	
549	Konica Minolta	Di 152		OK	
550	Konica Minolta	Di 200/Di 250/Di 251		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
551	Konica Minolta	magicolor 2450	OK	OK	OK
552	Konica Minolta	magicolor 5450	OK	OK	OK
553	Konica Minolta	magicolor 7300	OK		OK
554	Konica Minolta	Magicolor 7300	OK		OK
555	Konica Minolta	PagePro 1350W	OK		OK
556	Konica Minolta	PagePro 9100	OK		OK
557	Samsung	CLP-315	OK	—	OK
558	Samsung	CLP-500	OK	OK	OK

559	Samsung	CLP-510	OK	OK	OK
560	Samsung	CLP-620ND	OK	—	OK
561	Samsung	CLX2160	OK	—	OK
562	Samsung	ML-1510/1710	OK	OK	OK
563	Samsung	ML-1520	OK	—	OK
564	Samsung	ML-1610	OK	—	—
565	Samsung	ML-1640	—	—	OK
566	Samsung	ML-1660	OK	—	OK
567	Samsung	ML-1710	OK	—	OK
568	Samsung	ML-1750	OK	OK	OK
569	Samsung	ML-1915	OK	—	OK
570	Samsung	ML-2010	OK	—	OK
571	Samsung	ML-2250	OK	OK	OK
572	Samsung	ML-2550	OK	OK	OK
573	Samsung	ML-2580N	OK	—	OK
574	Samsung	ML-3471ND	OK	OK	OK
575	Samsung	SCX-4016	OK	OK	OK
576	Samsung	SCX-4100/4106/4116/4216F	OK	OK	OK
577	Samsung	SCX-4300	—	—	OK
578	Samsung	SCX-4623	—	—	OK
579	Samsung	SCX-5315	—	—	OK
580	Samsung	SRP 270		OK	
581	Panasonic	KX-P1121		OK	
582	Panasonic	KX-P1123		OK	
583	Panasonic	KX-P1124		OK	
584	Panasonic	KX-P1624		OK	
585	Panasonic	KX-P6500		OK	
586	TOSHIBA	E-161	OK(Parallel only)	OK	OK
587	TOSHIBA	Estudio-25		OK	
588	NEC	NEC P2200		OK	
589	NEC	NEC P3200		OK	
590	NEC	NEC P5300		OK	
591	NEC	NEC P8000		OK	
592	IBM	IBM Infoprint 20		OK	
593	IBM	Infoprint 1116	OK	OK	OK
594	IBM	Infoprint 1312	OK	OK	OK
595	IBM	Infoprint 1316	OK	OK	OK
596	IBM	Infoprint 1332	OK	OK	OK
597	IBM	Infoprint 1412	OK	OK	OK
598	Star	NX-2420		OK	
599	Sharp	AR-255		OK(Parallel only)	
600	Sharp	AR-265FG		OK(Parallel only)	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
601	Sharp	AR-M160(AR-NB2)		OK(Parallel only)	
602	Sharp	AR-M205		OK(Parallel only)	
603	Sharp	AR-M207		OK(Parallel only)	
604	Sharp	AR-M209			
605	Sharp	AR-M235		OK(Parallel only)	
606	Sharp	AR-M236			
607	Sharp	AR-M275		OK(Parallel only)	
608	Sharp	AR-M276			
609	Sharp	AR-M350		OK(Parallel only)	
610	Sharp	AR-M400		OK(Parallel only)	
611	Sharp	AR-M450		OK(Parallel only)	
612	RICOH	NF3570		OK	
613	Brother	DCP-385C	OK	—	—
614	Brother	MFC 4800	OK	OK	OK
615	Brother	MFC 4800J	OK	OK	OK
616	Brother	MFC 6800	OK	OK	OK
617	Brother	MFC 7220	OK	OK	OK
618	Brother	MFC 7420	OK	OK	OK
619	Brother	MFC 7820N	OK	OK	OK
620	Brother	MFC 8840D	OK	OK	OK
621	Brother	MFC 210C	OK		OK
622	Brother	MFC 235C	OK	—	—

623	Brother	MFC 240C	OK		OK
624	Brother	DCP-7030	OK		OK
625	Brother	HL1260		OK	
626	Brother	HL 2030	—	—	OK
627	Brother	HL 2035	—	—	OK
628	Brother	HL-2040			
629	Brother	HL-2140	OK	—	OK
630	Brother	HL-2170W	OK		OK
631	Brother	IntelliFax 2820	OK		OK
632	Zhendan	AD-166			
633	Zhendan	AD-216			
634	Zhendan	AD-226			
635	DELL	DELL 1100			
636	Zonerich	AB-80K			
637	OKI	OKI 5530			
638	OKI	OKI Microline 391		OK	
639	OKI	OKI B4350	OK	OK	OK
640	Jicheng	Jicheng 5890			
641	MITAC	MITAC		OK	
642	BENQ	BENQ CM3000	OK		OK
643	Avision	MF 3200	OK		OK
644	Avision	MF 3230	OK		OK
645	Citizen	GSX230		OK	
646	DATAMAX	I-4208		OK	
647	DATAMAX	I-4308		OK	
648	DOCUJET	1610F	OK	OK	OK
649	DOCUJET	UA1610	OK	OK	OK
650	FUTEK	F8000		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
651	FUTEK	F84+		OK	
652	FUTEK	F86+		OK	
653	Kyocera	FS-1010	OK	OK	OK
654	Kyocera	FS-1010KX	OK		OK
655	Kyocera	FS-1020	OK	OK	OK
656	Kyocera	FS-1920	OK	OK	OK
657	Kyocera	FS-2000D	OK	OK	OK
658	Kyocera	FS-820	OK	OK	OK
659	Kyocera	FS-920	OK	OK	OK
660	Kyocera	FS-6020	OK	OK	OK
661	Kyocera	FS-6026	OK	OK	OK